

B303

Video Projector Control System

Power-On the computer and the VCR before turning on the Video Projector (VP).

Power-On the VP (it's the **Green** one on the VP remote control).

To view the VCR through the VP, push the "Input" button on the VP remote until "Video" appears on the wall-screen.

To view the computer through the VP, push the "Input" button on the VP remote until "Input A" appears on the wall-screen.

The audio for the VCR runs directly to the VP. The volume for the video can be adjusted with the "Volume + -" buttons on the VP remote.

The picture on the screen can be temporarily blanked-out by pushing the "Picture" muting button on the VP remote. Push it again to put the image back on screen.

To turn off the VP, press the "**Green**" button on the VP remote. A confirmation message will appear on screen. Press the "**Green**" button again.

Trouble?

Randy x7393 (7:00a – 3:00p)

Educational Technology Center