

B408

Video Projector & Computer

Power-On the computer before turning on the Video Projector (VP).

Power-On the VP with the red “Power” button on the VP remote control.

To view the computer through the VP, push the “Comp2/YCbCr” button on the VP remote.

For now, video tapes must still be viewed through the TV as usual. Sometime in the future the TV/VCR will be removed, a VCR and sound system will be added, at which point video tapes will be viewed through the VP as well.

The picture on the screen can be temporarily blanked-out by pushing the “AV Mute” button on the VP remote. Push it again to put the image back on screen.

To turn off the VP, press the red “Power” button on the VP remote. A confirmation message will appear on screen. Press the “Power” button again.

Trouble?

Randy x7393 (7:00a – 3:00p)

Educational Technology Center